


PARTS LIST MODEL H3392



No.	Description	Part No.
1	Retaining Ring (10/pk)	00009M-03
2	Dome Stop	15097P-01
3	Earseal (pair)	18316G-02
4	Filter (1 each)	14096P-09
5	Filter (1 each)	25629P-03
6	Screw/Grommet Kit (4 pk)	18900G-47
7	Earphone Assembly	10376G-20
8	PCB Assembly	18289G-13
9	Dome Filter	26475P-02
10	Push Button Switch	09851P-17
11	Headpad Assy	40075G-02
12	Headband Spring	15247P-01
13	Temple Pad Assy Kit	18900G-37

No.	Description	Part No.
14	Stirrup & Clamp Kit	22378G-08
15	Switch Cap Kit	41090G-13
16	Switch Guard	13148P-01
17	Left Dome	15253P-17
18	Boom Guide Kit	12840G-01
19	Microphone Cord Assy Kit	10405G-05
20	Communication Cord Assy Kit	18028G-34
21	Microphone Boom Assy	12765G-04
22	DC-1A Microphone w/Cord	12948G-14
23	Microphone Cord Assembly	10516G-14
24	Screen, Wind, Mic	40062G-06
25	DC-1A Microphone	18920G-04

ELECTRICAL SCHEMATIC
MODEL H3392

