

Setting up the CMax Key Code for an Avidyne EX5000, EX600, or EX500 in Jeppesen Distribution Manager

Before downloading and transferring the charts database update for your Avidyne EX5000, EX600, or EX500 using the Jeppesen Distribution Manager application, you must first obtain a CMax Key Code for your MFD system.

1. Log into the JDM application, then click the '**More ...**' button next to '**Avidyne EX5000, EX600, EX500 - Electronic Charts**':



If you are using JDM Mobile, tap the arrow under 'Avidyne EX5000, EX600, EX500 :: Electronic Charts':



2. Click '**Set Avidyne CMax Key Code...**':



Next Cycle: 26-2019
Issue Date: 27 DEC 2019

Serial Number: [REDACTED]

[Set Avidyne CMax Key Code...](#) 

Media Required:
Removable Media (FAT16)

[REDACTED]

If you are using JDM Mobile, tap 'Edit' next to CMax Key Code:

Avidyne EX5000, EX600, EX500 :: Electronic Charts
Cycle: 25-2019
Issue Date: 13 DEC 2019 

 Download
Download data to this device

Current Cycle: 25-2019
Issue Date: 13 DEC 2019
Next Cycle: 26-2019
Issue Date: 27 DEC 2019
Subscription Renewal: -
Serial Number: [REDACTED]
CMax Key Code: Applied [Edit](#) 
Subset: Not Applied [Select Coverage](#)
Coverage: Full USA IFR Africa IFR Africa IFR Military Supplement Europe and

- Record the JeppView Serial Number that appears on the next window, then click the '<https://www.MyAvidyne.com>' link to open the MyAvidyne.com page in a web browser:

Avidyne CMax Key Code 

Avidyne CMax Approach Chart customers must retrieve their customer-specific key code from the MyAvidyne.com web site in order to enable the transfer of JeppView Chart data into the FlightMax MFD.

You will need to log into MyAvidyne.com with your Avidyne Username and Password, and then copy and paste the JeppView software serial number into the MyAvidyne site. The MyAvidyne web site will give you a CMax Key Code that you must paste into this dialog. This key will be stored by Jeppesen, and you will not need to enter it again.

JeppView Serial Number:
[REDACTED] 

Avidyne CMax Key Code:

<https://www.MyAvidyne.com>

OK Cancel

Avidyne CMax Key Code

JeppView Serial Number:

Avidyne CMax Key Code:

Avidyne CMax Approach Chart customers must retrieve their customer-specific key code from the MyAvidyne.com web site in order to enable the transfer of JeppView Chart data into the FlightMax MFD.

You will need to log into MyAvidyne.com with your Avidyne Username and Password, and then copy and paste the JeppView software serial number into the MyAvidyne site. The MyAvidyne web site will give you a CMax Key Code that you must paste into this dialog. This key will be stored by Jeppesen, and you will not need to enter it again.

<http://www.MyAvidyne.com>

OK Cancel

4. Click the 'Click here to register a Cmax Code without logging in.' link at the bottom of the login area on the MyAvidyne.com page:

User ID

Password

Login

[Create New Account](#)

[Forgot Password?](#)

[Click here to register a Cmax Code without logging in.](#)

5. Enter your Avidyne MFD Serial Number and the JeppView Serial Number (Jeppesen Software S/N) that appears in the JDM application, then click **Get Code**. The Avidyne MFD Serial Number will be the eight-character serial number you can find on the "Aux" page on the MFD in the aircraft.

CMax Key Code

To enable your CMax Account you must obtain a key code. The key code is generated from your Jeppesen Software Serial Number. To obtain your Jeppesen Software Serial Number, please contact Jeppesen at 1-800-621-5377.

Please enter your Jeppesen Software Serial Number below and press "Get Code". Be sure to enter your Jeppesen Software Serial Number without dashes or spaces. This number is also case-sensitive, so enter it exactly as issued by Jeppesen. The "key" will appear in the field labeled: "CMax Key Code". If your CMax Key Code begins with a '#', be sure to include this symbol as part of your key.

MFD Serial Number		Eight character serial number. If S/N is less than eight characters, left pad with zeros. For example, D1234 becomes 000D1234.
Jeppesen Software S/N		This code is case-sensitive. Enter it exactly as issued by Jeppesen.
Get Code		CMax Key Code

6. Enter the CMax Key Code into the JDM application, then click OK. The best way to ensure the code is entered correctly is to highlight it, then copy and paste it from the MyAvidyne.com site into the JDM application. Double-check that there are no leading or trailing spaces in the Avidyne CMax Key Code in the JDM application by highlighting it (click-hold and drag the cursor across the Avidyne CMax Key Code). If there are any leading or trailing spaces, they will also be highlighted.

Avidyne CMax Key Code [X]

Avidyne CMax Approach Chart customers must retrieve their customer-specific key code from the MyAvidyne.com web site in order to enable the transfer of JeppView Chart data into the FlightMax MFD.

You will need to log into MyAvidyne.com with your Avidyne Username and Password, and then copy and paste the JeppView software serial number into the MyAvidyne site. The MyAvidyne web site will give you a CMax Key Code that you must paste into this dialog. This key will be stored by Jeppesen, and you will not need to enter it again.

JeppView Serial Number:

Avidyne CMax Key Code:

<https://www.MyAvidyne.com>

Avidyne CMax Key Code

JeppView Serial Number:

Avidyne CMax Key Code:

Avidyne CMax Approach Chart customers must retrieve their customer-specific key code from the MyAvidyne.com web site in order to enable the transfer of JeppView Chart data into the FlightMax MFD.

You will need to log into MyAvidyne.com with your Avidyne Username and Password, and then copy and paste the JeppView software serial number into the MyAvidyne site. The MyAvidyne web site will give you a CMax Key Code that you must paste into this dialog. This key will be stored by Jeppesen, and you will not need to enter it again.

<http://www.MyAvidyne.com>